CREW: 78 WORK ORDER TYPE: MODIFICATIONS			01-19846-19		01-19846-19	ISSUE DATE 01/06/11	Pa	ge 1 Of 3		
Orig: Plann	nator : TRAVIS SMITH	Schedule Date	: 09	-	3/02	Date Completed:		Failure Code		_
	ing No :	Clearance	: NC			Completed By :		Signature		
	No/Cat: 5COXST 0	Tag Request Text ID	:			Accepted By :		Signature	:	
Shut		Frequency	: NOT SCHEDULED		necepted by .		515.14C41C	·		
Ref 1	Job Scope	Last Reading	: No		Safety and Additional I		W=Whse ** R Emp No	-	odes Legend ** =Tag TL=Tool aily ** Hours	P=Plan Delays Code/Hrs
1	INSTALL THE NEW MEGAWATT 1		2	1	USE APPROPRIATE CAUTION	DURING				
	THE BI-POLE CONTROLS.				INSTALLATION OF THE TRA					
	**************************************		*		CHECK THE CT CIRCUITS BEFORE STARTING THE					
	1. WORK WITH THE ENGINEERS TO INSTALL				INSTALLATION PROCESS.				·	
	THE NEW MEGAWATT TRANSDUCERS. 2. NOTE ON THIS WORK ORDER ALL PROBLEMS									
	FOUND AND CORRECTIVE ACTION	ON TAKEN.								
	************	******					 			
									* ` 	

								* IMPORTANT 1		
									YOUR OWN SAFET	
									PPE IS WORN F	
							JOB YOU ARE	DOING. IF	OU HAVE ANY QU	ESTIONS

Job Feedback/Historical Notes:

IP7_005528



CONCERNING THE WORK RULES, SAFETY CODES, OR REQUIRED PPE, PLEASE CONTACT YOUR SUPERVISOR.

*	* *	Work	Order	Parts	List	**

	Part No	Description	PO/Req/SIR	Date Due	U/M	Reqd	Commit	Issued/Rcvd
1	50176	TY-RAP, CABLE	S 224235	09/04/02	EA	200	0	200
2	50177	TY-RAP, CABLE	S 224235	09/04/02	EA	200	0	200
3	51753	TY-RAP, CABLE	S 224235	09/04/02	EA	200	0	200
4	51754	TY-RAP, CABLE	S 224235	09/04/02	EA	1000	0	1000

CREW: 78 WORK ORDER TYPE: MODIFICATIONS 01-19846-19 ISSUE DATE 01/06/11 Page 3 Of 3

		** Work Order Tools	List **			
Ln	Tool No	Noun Qualifier	Measure 1	Measure 2	Measure 3	Rqd
1	634	STRIPPER, WIRE	AUTO			1